

Multi-Frequency Ultrasonic Generator

Multi-Soft Series

We suggest the best solution for your cleaning process.

- Suitable for cleaning SEMI, Liquid Crystal, Lens, Disk Drives, and Displays.



Our multi-frequency ultrasonic cleaner; “Multi-Soft” series allows cavitations cleaning for very precise applications. It has adjustable frequency, ultrasonic generating time, power and cycle number. Four frequencies (40/72/104/170kHz) and our new dual sweep technology are available for the cavitation cleaning of very precise applications. When you want to use multiple frequencies in a traditional ultrasonic

cleaning system, you have to have multiple ultrasonic generators and transducer units to match different frequencies. Our “Multi Soft” generator is capable of handling multiple frequencies with one generator and transducer unit because of digital circuit technology.

Multi-Soft Series Technical Data			
MODEL	MS3G	MS6G	MS9G
FREQUENCY	40kHz/72kHz/104kHz/170kHz Multi-Frequency		
POWER	300W	600W	900W
PROGRAMMING FEATURES	Frequency/Power/Time(0.75-3.270sec)/Cycle Number		
POWER CONTROL	Digital setting by PLC controller		
SWEEP	Dual Sweep Function		
OUTER DIMENSION	(W)331*(D)420*(H)153 mm		
WEIGHT	9.1 kg		
INPUT POWER	AC200V, 50/60Hz		

Contact:



Malaysia - Thailand

ABSOTEC CO., LTD.
 70/26 Moo 5, Lumlugga Klong 6, Bungkumploy,
 Lumlugga, Pathumthani 12150 Thailand
 Tel: +66 (0) 2532 6103
 Tel: +66 (0) 2178 2553
 Fax: +66 (0) 2532 6102
 E-mail: enquiry@absotecthailand.com
 URL: <http://www.absotecthailand.com>
 URL: <http://www.greeninnotec.com>