

MULTI LIGHT VIEWING BOOTH

Super Light-VI



Multiple light sources are available for choice of difference combination of illumination meeting the requirements form various industries. Super Light-VI is built in accordance with ASTM D1729 standard for visual evaluation of color differences of opaque materials

Display : LCD-Display name of illuminants, Color Temperature, used time of each iluminant

Color : Internal & External-Munsell N7 Neutral Grey (Lusterless)

Select Switch : Membrane Switch

External Area : 670 x 470 x 525 mm (W x D x H)

Viewing Area : 660 x 430 x 390 mm (W x D x H)

Weight : 24Kg (53.0Lb)

Voltage : 100-120, 220-240 VAC. 50/60 Hz

Light Sources

STANDARD (5 Lamps)

Day Light (CIE D65)
Average North Sky Daylight at 6500K

Cool White Fluorescent (CWF, CIE F2)
Commonly used in office and store at 4150K

Incandescent Light (A)
Typical home lighting at 2856K

Tri-phosphor Fluorescent lamp(TL84, CIE F11)
Commonly used in Europe at 4100K

Ultraviolet Light BLB (UV)
Use together with another illuminants & check for optical brighters, fluorescent pigments and dyes

OPTIONS

Day Light (D75)
North Sky Day Light at 7500K

Day Light (D50)
Noon Sky Day Light at 5000K Commonly used in graphic arts

Horizon Day Light (HOR)
Simulates sunrise and evening sunset at 2300K

Ultralume 30 (U30, CIE F12)
Commonly and used in America at 3000K

TL83, U41, ect



Malaysia - Thailand

ABSOTEC CO., LTD.
70/26 Moo 5, Lumlugga Klong 6, Bungkumploy,
Lumlugga, Pathumthani 12150 Thailand
Tel: +66 (0) 2532 6103
Tel: +66 (0) 2178 2553
Fax: +66 (0) 2532 6102
E-mail: enquiry@absotecthailand.com
URL: <http://www.absotecthailand.com>
URL: <http://www.greeninnotec.com>

ORDER SELECTION

Type-A (Standard) 5 lamps : D65, CWF, A, UV, TL84 or U30

Type-B 6 lamps : D65, CWF, A, UV, TL84, U30

Type-C 6 lamps : D65, CWF, A, UV, TL84, HOR

Type-D 6 lamps : D65, CWF, A, UV, U30, HOR